

Diagram 7



7. Use Tact Switch S2 or S3 to change 00 or 01. To confirm and return to normal operation, press S1 with confirm: 01. To ignore setting and return to normal operation, press S1 with confirm: 00.

CAUTION

1. **SWITCH OFF** the mains supply before any installation, maintenance or repair work is carried out.
2. **DO NOT** work on live equipment unless it is essential to do so, in which case extreme care must be taken to avoid electrical shocks, including the use of rubber mats.
3. Installation, maintenance or repair must only be carried out by a competent person who is trained on this equipment.
4. Replace all covers on completion of work and ensure the unit is safe for installation and use.

EEC DIRECTIVES

These components comply with the relevant EEC Directives when used on lifts



Installation and setting instructions

Time & Date Settings

UL60, ULS60 & ULS65

Publication Number: II118/0806

Part Number:

Important

These instructions must remain with the product to ensure correct installation. Please visit our website for extra copies if required.

If you have any installation problems or questions, please contact:

UK (LiftStore)	020 8538 1770
Canada (Dupar)	519 624 2510
USA (The Fixture Company)	847 419 1419
Australia (Australian Lift Components)	+612 9603 0200
Australia (LiftMaterial)	+612 9310 4288

Dewhurst plc

Inverness Road Hounslow TW3 3LT United Kingdom
tel +44 (0)20 8607 7300 fax +44 (0)20 8572 5986

Diagram 1



1. Press Tact Switch (S1) to change setup mode. **Diagram 1** will appear. Use tact switch S2 or S3 to adjust the year if necessary. Press S1 to advance to month entry. Refer to **Diagram 2**.

Diagram 2



2. Press Tact Switch S2 or S3 to adjust the month if necessary. Press S1 to advance to date entry. Refer to **Diagram 3**.

Diagram 3



3. Use Tact Switch S2 or S3 to adjust the date if necessary. Press S1 to advance to hour entry. Refer to **Diagram 4**.

Diagram 4



4. Use Tact Switch S2 or S3 to adjust the hour if necessary. Press S1 to advance to minute entry. Refer to **Diagram 5**.

Diagram 5



5. Use Tact Switch S2 or S3 to adjust the minute if necessary. Press S1 to advance to date format entry. Refer to **Diagram 6**.

Diagram 6



6. Use Tact Switch S2 to S3 to adjust the date format if necessary. Refer to **Table 1** for the date format. Press S1 to advance to Daylight Saving entry. Refer to **Diagram 7**.

Format	Horizontal Example	Vertical Example	Remark
00	15:00 20/01/2004	15:00 20/01/2004	English, French, Spanish
01	15:00 20-01-2004	15:00 20-01-2004	Dutch, Portuguese
02	15:00 20.01.2004	15:00 20.01.2004	German
03	15:00 20/01/2004	15:00 20/01/2004	Italian
04	15:00 20 January 2004	15:00 20 January 2004	English
05	15:00 20 januari 2004	15:00 20 januari 2004	Dutch
06	15:00 20 janvier 2004	15:00 20 janvier 2004	French
07	15:00 20 Januar 2004	15:00 20 Januar 2004	German
08	15:00 20 Gennaio 2004	15:00 20 Gennaio 2004	Italian
09	15:00 20 de Janeiro de 2004	15:00 20 de Janeiro de 2004	Portuguese
10	15:00 20 de enero de 2004	15:00 20 de enero de 2004	Spanish
11	15:00 dinsdag 20 januari 2004	15:00 dinsdag 20 januari 2004	Dutch
12	15:00 Mardi 20 janvier 2004	15:00 Mardi 20 janvier 2004	French
13	15:00 Dienstag, 20 Januar 2004	15:00 Dienstag, 20 Januar 2004	German
14	15:00 Martedì 20 Gennaio 2004	15:00 Martedì 20 Gebbaio 2004	Italian
15	15:00 Terça feira, 20 Janeiro de 2004	15:00 Terça-feira, 20 de Janeiro de 2004	Portuguese
16	15:00 Martes, 20 de enero de 2004	15:00 Martes, 20 de enero de 2004	Spanish